

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019

REPLACES: 00.00.00 REVISED: 21.12.11

Australia

NB7T140SY

FITTING INSTRUCTIONS

TOYOTA FJ CRUISER 76MM SERIES 2 NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

- 1. Remove M8 bolt from power steering cooler tube support on driver side chassis rail between radiator support and rear of crash can. See figure 1.
- 2. On driver's side: Slide ECB Steel mounting bracket (supplied) between chassis rail and power steering cooler mount, attaching both parts using M8 x 1.25 x 40 bolt, spring washer and flat washer and M12 x 35 x 1.25 bolt, spring washer and flat washer (supplied). **TIGHTEN ALL BOLTS. See figure 2.**
- 3. Repeat for passenger's side. NOTE: Passengers side does not have power steering cooler mount.
- 4. Slide ECB protection bar into position, taking care not to damage plastic bumper cover, and fit 3/8 x 1 ½ bolts, flat washers, spring washers and nuts (supplied). **FINGER TIGHTEN ONLY.**
- 5. Align ECB protection bar to vehicle. See figures 3 and 4.
- 6. TIGHTEN ALL BOLTS.

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

FITTING KIT

2 – ECB steel mounting brackets	2 – M12 flat washers
2 – M8 x 1.25 x 40 bolts	$4 - 3/8 \times 1\frac{1}{2}$ bolts (2 bolts to be left out for packaging)
2 – M8 spring washers	8 - 3/8 flat washers (4 washers to be left out for packaging)
2 – M8 flat washers	4 – 3/8 spring washers
2 – M12 x 1.25 x 40 bolts	4 - 3/8 nuts (2 nuts to be left out for packaging)
2 – M12 spring washers	

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia



Figure 1: Drivers side of vehicle showing power steering bracket with bolt removed.



Figure 3: Front view, 76mm Nudge Bar




Figure 2: Drivers side mount fitted.



Figure 4: Side view, Series 2 Nudge Bar.



Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.	
Product Part No.	Product Invoice No. Make, model, and year of vehicle:	
Product Description:		
Product Work Order No.	Company your from/Company product purchased from:	
Date of Fitment:/ Was the fitting hardware supplied complete?	Yes No	
If no what was not supplied		
Did the installation go well?	Yes No	
Please provide comments		
Please draw diagrams if you need to.		
rease draw diagrams in you need to.		

Post to Reply Paid 122 PO Box 122 Margate QLD 4019 Fax to (07) 3283 1168



Final wrap check:

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

DESPATCH CHECKLIST NB7T140SY

ND/114051		
Work Order #		
Finish:		
Transport:		
Due Date:		
O 2 – ECB s O 1 – Bolt F	steel mounting brackets. Kit.	See other side of this page for photos of all mounts
Is this product "the best it can be" Yes/		
All parts <u>checked</u> a	nd <u>completed</u> by:	
Nut and bolts:		Date//
Order control:		Date//

_Date__/__/__



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia

